


The SafeWork Sensor

How It Works



Volume
Up & Down



Touch Screen

Easily check out the device, review daily safety information, watch training videos, and review important tips.

Device ID

(StrongArm decal with barcode)

Charging Pin

Primary Functions

1. Checkout Devices

Each Industrial Athlete selects their Name/Employee ID from a preloaded list displayed on the device touch screen.

2. Uploading Data


Network connection is required to upload sensor data. Easily connect via Wi-Fi or a StrongArm provided hotspot.


3. Device Charging


The supplied charging dock should be plugged into the power source at all times. Plug in the device with the supplied charging cable. A green LED light signals active charging status.



Device Check-Out



- 1 Select your language



- 2 Select your name or employee ID from the list




- Press confirm to verify the selection


- 3 (optional) Review the daily Safety Score metrics screen and the Haptic Alert informational screen



- 4 The device is ready to use and can be placed in the harness as instructed by program administrator





- The display then shows an active session along with other information


- Additional information about how to improve your Safety Score and what is considered a High-Risk Bend Angle

Device Check-In

When you are ready to check the device in, swipe the "Swipe to End Session" button on the screen to complete your session.

Connect the device to the charging cable so it's ready for the next user

